

PRODUCT SPECIFICATION

SAFETYWARE 9800 Dual Cartridge Silicone Full Face Air Purifying Respirator

- A full-face respirator with face seal, nose cup, and silicone headgear enhance ease of donning on & off, comfort, durability, and ease of cleaning.
- Large Polycarbonate lens provide a wide viewing angle & better visibility.
- Polycarbonate visor with anti-fog and anti-scratch treatment.
- MAX FLOW exhalation valve efficiently reduces the temperature, humidity, and CO₂ gases inside the respirator. It is protected with a vertical downward flow cover.
- Screw-type exhalation valve cover.
- Bayonet Filter Connection system.
- 4-point harness for a secure, quick and easy fit.
- Approved by SIRIM-DOSH.

ITEM CODE

ITEM CODE	SIZE
9800-M	M
9800-L	L

APPLICATIONS

- Welding
 - Wood working
 - Mining
 - Pharmaceutical Manufacturing
- Environmental Cleanup
 - Laboratory Work
 - Emergency Response
 - Construction

TECHNICAL DATA

MATERIAL	Face piece, nose cup and headgear : Silicone
	Visor : Polycarbonate
COLOR	Blue
STANDARD	BS EN 136 : 1998 AS/NZS 1716:2012
DOSH APPROVAL NO.	9800-M : JKKP/2024/12-01/06/00014/0001 9800-L : JKKP/2024/12-01/06/00014/0002
CARTON DIMENSION	42 (L) x 31 (W) x 27 (H) cm

Item Code: 9800



USAGE RESTRICTION

- This respirator does not supply oxygen; use in areas adequately ventilated without oxygen deficiency that do not contain explosive atmospheres.
- Do not use in environments where the concentration level of the contaminant is Immediately Dangerous to Life or Health (IDLH).