

PRODUCT SPECIFICATION

SAFETYWARE EXPLORER I Safety Helmet

- Made using high-density ABS shell for excellent top impact protection.
- Front brim is designed to protect wearers' face from sun, rain, and reduce glare.
- Comes with 8 points PE suspension harness for comfort fit, as well as helps to absorb and dissipate impact.
- Slots on both sides allow fitting with various accessories.
- Available in two types: Non-vented and vented.
- Non-vented type helps to reduce exposure to high voltage conductors.
- Vented type allows refreshing airflow around the space between head and helmet.
- Two cradle available: webbing type and plastic type.
- Comes with chin strap.



SERVICE LIFE

- Suspension System : 6 months (Plastic Harness, Tape Harness and Ratchet Harness)
- Helmet Shell : 2 years (with careful handling and proper maintenance, maximum service life can extend up to 5 years)

APPLICATIONS

- General industry and manufacturing
- Construction
- Electric/utilities
- Oil and gas

TECHNICAL DATA

SHELL MATERIAL	ABS
CRADLE & HEADBAND MATERIAL	PE
CRADLE	Webbing type, plastic type
LOCK	Slide lock
COLOURS	White, yellow, blue, red, orange, brown, purple, grey, green.
SHELF LIFE	5 years
DOSH APPROVAL NO.	SH01SP : JKKP/2024/12-01/03/00038/0001 SH02SP : JKKP/2024/12-01/03/00038/0002 SH01SW : JKKP/2024/12-01/03/00038/0003 SH02SW : JKKP/2024/12-01/03/00038/0004

ITEM CODE

ITEM CODE	HELMET	CRADLE TYPE	LOCK TYPE
SH01SP	EXPLORER I Vented Safety Helmet	Plastic Harness	Slide Lock
SH01SW	EXPLORER I Vented Safety Helmet	Webbing Harness	Slide Lock
SH02SP	EXPLORER I Non-Vented Safety Helmet	Plastic Harness	Slide Lock
SH02SW	EXPLORER I Non-Vented Safety Helmet	Webbing Harness	Slide Lock

SAFETYWARE SDN. BHD. (632971-X)

Plot 237, Lengkok Perindustrian Bukit Minyak 3,
Bukit Minyak Industrial Estate,
14100 Simpang Ampat, Penang, Malaysia

Tel : +604-5023 882 | Fax : +604-5081 882
www.safetyware.com | info@safetyware.com

It is the product users' responsibility to conduct all the appropriate evaluations & testing to determine the suitability of SAFETYWARE products for use in a particular environment or purpose. SAFETYWARE disclaims all warranties other than as expressly provided.

Date created: 20/10/2022

Revision: 05

Date revised: 06/03/2024