

PRODUCT SPECIFICATION

SAFETYWARE Guardian HD Vented Safety Helmet (Ratchet)

- The SAFETYWARE Guardian HD Industrial Safety Helmet (Ratchet Type) is designed for superior comfort and reliable head protection in industrial and construction environments.
- Built from tough HDPE material, the helmet features an 6-point molded shock-absorbing suspension system for optimal impact resistance.
- The soft fabric sweatband and 2-point chinstrap provide added comfort and stability, while the ratchet mechanism allows quick and easy adjustment for a perfect fit.
- Available in White and Yellow, this non-vented model is suitable for environments where debris or splash protection is a concern.

APPLICATIONS

- Construction Industries
- Oil & Gas Industries
- Logistics & Warehousing
- Mining & Quarry Operations
- General Maintenance & Engineering Work

TECHNICAL DATA

SHELL MATERIAL	High-Density Polyethylene (HDPE)
COLOR	Yellow and White
SIZE	52–63 cm
DESIGN	Vented
CRADLE TYPE	Webbing Harness
ADJUSTMENT TYPE	Ratchet
CHINSTRAP	2-Point Chinstrap
SUSPENSION	6-Point Moulded Shock Absorbing System
SHELF LIFE	2.5 Years
STANDARD	ANSI/ISEA Z89.1-2014 (R2019), Type I, Class C

SERVICE LIFE

- Suspension System : 12 months
- Helmet Shell : 2 years (with careful handling and proper maintenance)

SH03RS



STORAGE

- Store in a cool, dry and well-ventilated area.
- Keep away from sunlight, heat, and UV exposure.
- Avoid contact with chemicals, fuels, oils, paints and corrosive substances.
- Do not place heavy objects on top of the helmet.
- Use proper packaging during storage and transport.

CLEANING AND MAINTENANCE

- Clean using mild detergent and lukewarm water.
- Air dry naturally
- Do NOT use solvents, thinners, fuels, paints or adhesives.